


# OSIsoft PI System Supporting Process Decisions

Presented by **Seamus McGrath** 



#### Novartis: OSIsoft PI System Supporting Process decisions

Leveraging the capability of OSIsoft PI System to support process decision making in real-time where no process control is required





#### **Business Challenge**

 Complex processing of production data performed on control system required offline testing and online testing which is intrusive and time consuming

#### **Solution**

 Elevate all of the process data to the Historian and deliver the calculations using BI and testing and validate without interfering with Production

#### **Results and Benefits**

- NIR Batch report
- Faster turnaround of change
- Reduced cost of change
- No process control Execute logic outside PCS

#### Healthcare

- Pharmaceuticals
- Sandoz
- Vaccines & Diagnostics
- OTC
- Animal Health
- Alcon
- 140,000 Associates across
   140 countries
- Pharma/TechOps/ChemOps
  - API DS manufacturing



# OSIsoft PI System Supporting Process decisions - *background*

- NIR First Installed in 2008.
- System provides PAT data about the residual solvent (ESTP/CHXA) in the product in the Dryer
- Prior to NIR End Point Tool, IPC samples had to be taken at the end of each Drying Phase, with a delay for testing time.
- NIR provides multiple parameters, with different acceptance criteria for each drying Phase as well as process parameters such as vacuum, temperature and time – a decision on end point requires careful examination of all of the criteria

# OSIsoft PI System Supporting Process decisions - *traditional approach*

- DCS initially considered for giving users Traffic lights, to either advance the Drying Phase or Manually sample.
- System would be complex to implement on DCS
  - Difficult to simulate
  - Testing in the live plant
  - Changes/optimizations causes process interruptions for downloads
  - A lot of consumption of DCS tags/space
  - Poor graphic capability (legacy PCS)
- We had a resource constraint and there was always a greater priority

# OSIsoft PI System Supporting Process decisions - alternative approach

- OSIsoft PI System was then explored as a solution as it contains all PCS data and NIR data
  - Premise being it was information only and not process control
  - PI System very well embedded in Ringaskiddy and trusted
- PI ActiveView was determined to be the best display solution, used on site since 2003 for web based displays and reports.
  - NIR Report could be created, validated, released and controlled via a web content server for the PI System (Novametrics)
- Integrated VBA and PI SDK have the flexibility and power to build a Traffic light display that can reliably show the current state of drying.

#### OSIsoft PI System Supporting Process decisions – *implementation approach*


 Watchdog Parameters indicate an error with the NIR or associated system or drying went over time limits, operator should switch to Manual sampling in this case.

 NIR and Dryer Process Values indicate via traffic light if a good condition is met. Once all conditions are met Operators are prompted to advance phase or sample

depending on Drying Phase.

 It also displays the "Trigger Value", the closest value in the time period to the limit.

Located on a Control Room PC




#### OSIsoft PI System Supporting Process decisions – *implementation approach*

Current Batch/Phase/drying step

Report can show different conditions for different drving

phases.

PC/Server Heartbeat



#### **OSIsoft PI System Supporting Process** decisions - benefits


- Reduction in the amount of resources spent on sampling (QC)
- Reduces delay time between phases and the overall drying time
  - Reduced deviations via avoiding over drying


Allows users to quickly document the NIR Parameters met requirements with authenticated Print function.


Changes can be made without downloads or alterations to PCS.


- Complex conditions can be handled.
- Report can be opened on any CONNECT PC.
- Lower cost
- Reduced Energy consumption

























































































































































































































































































# OSIsoft PI System Supporting Process decisions – *Next Steps*

Quality alarming via the PI System



- No process control
- Key enabler for CPV and EBR

#### **Seamus McGrath**

Seamus.mcgrath@novartis.com
Head of Automation and IT
Novartis Ringaskiddy Limited

#### Please don't forget to.....

Complete the Online Survey for this session



Eventmobi.com/emeauc13

Share what you saw with friends on Twitter, Facebook or Linkedin!

**#UC2013** 







