

Energy Monitoring and Targeting using the PI System and RtEMIS

Presented by **Keith Kirkham, Energy Manager,**
Irving Tissue Toronto



IRVING TISSUE

Presentation will be in 3 parts



Our energy issue

Solution using the PI
System infrastructure

Results and next
steps



IRVING TISSUE

Irving Tissue Toronto



- 1551 Weston Road, Toronto



IRVING TISSUE


Who We Are

- Manufacturer of household tissue products
- Products include facial and bathroom tissue, and paper towels
- Both branded and private label products



IRVING TISSUE

What was our energy issue?



IRVING TISSUE

Our operation is energy intensive

- Large integrated tissue manufacturing plant
 - 3 tissue paper machines and 9 converting/packaging lines
- One of the largest industrial single site users of electricity & natural gas in Toronto



IRVING TISSUE

Energy Measurement presented an opportunity

- Mostly local metering
- Process measurements well done
- Electrical metering was uneven
- Data not accessible for analysis
- **We did not know what we were using or how effective we were**



What was our energy opportunity?

- Our 3rd largest cost- but not measured in real time
- Information not accurate for budgeting, forecasting, etc.
- Difficult to tell if there were opportunities to improve our energy performance
- Need to measure in order to manage



What did we want to measure?

- Electricity- 13 existing meters plus 17 new ones (total 30 meters)
- Natural gas flows- 7 existing plus 2 new (9 meters)
- Steam flow- 6 existing meters




Why monitoring and targeting?

- Need for monitoring is obvious:
 - Gather and store information in real time to view & understand
- Targeting is less obvious:
 - Best way to measure energy effectiveness
 - More meaningful than KW/unit
 - Indication of ‘How are we doing?’ AND “How should we be doing”
 - Answer: Are we having a good energy day???



Energy/unit production is not meaningful



IRVING TISSUE

How does targeting work?

- Mathematical prediction of energy use
- Target calculation is done by regression analysis of historical information
- Inputs include all variables that can influence the amount of energy used:
 - Production rate, speed, temperature, humidity, product qualities, etc., etc., andetc.



Why is Targeting superior to energy/unit?

Energy/unit

- Two ways to manipulate-
 - Change energy
 - Change units
- Not intuitive (good?, bad?)
- Depends on a linear relationship
- Only meaningful when you have 0 energy with 0 units- not a real life situation

Targeting

- Provides an immediate measure- above/on/below
- Meaningful in all situations regardless of inputs




IRVING TISSUE

3 situations where a target is useful

- Usage is above target- *what is wrong, and how can we fix it.*
- Usage is on target- *how can we improve (continuous improvement)*
- Usage is below target- *why? How do we keep doing this? (Make it permanent!)*



Our solution- PI System Infrastructure



IRVING TISSUE

We had many selection criteria

- Inputs from several different sources and proprietary platforms
- Archive data for 2 years
- View energy & process data together
- Extract data for analysis and reporting
- Universal access to information via business LAN
- Not another island or sandbox
- Preserve data security-on site
- Calculate and display energy usage & targets accurately
- Customer support



The PI System was a logical choice

- All of the criteria were resolved with a solution based on the PI System
- Growing use of the PI System within our corporation
- The PI System provided us with a platform for growth






met our criteria

- Based on the PI System
- Web based displays on corporate LAN
- Target calculation expertly done
- Proven installation on our corporate network



IRVING TISSUE


Our system



IRVING TISSUE


Start-up Screen for RtEMIS

Energy
Account
Centers




IRVING TISSUE

Screen print of Data View



IRVING TISSUE

DataView Time range & energy units can be easily changed



Beginning & end times are easy to change




IRVING TISSUE

Report view shows more information




IRVING TISSUE

CUSUM chart is major feature



IRVING TISSUE

Target calculator is easy to use



IRVING TISSUE

System features

- Time range is easily selectable
- Energy units are easily changed
- Real time cost is displayed
- Informative built-in reports
- Target values are written back into the PI System
- Custom reporting easily done with PI DataLink



Results and next steps



IRVING TISSUE

What we have gained

- No longer have to guess- *we know real time and historical information-*
 - *Consumption*
 - *cost*
 - *performance*
- Information is available to justify projects and operating decisions
- We know if we had a good energy day



Other key learnings

- M&T is a tool- it's not the solution
- Needs to be used as an aid- not as a threat
- Observed belief- energy is beyond our control
- Immediately see results of actions taken
- *If you measure it you can manage it.*



On going opportunities

- Target calculation is on-going issue:
 - Is the process off, or is it the target
 - Shoot the messenger
- Increase use of the M&T system
- Overcome the belief that energy is not controllable
- Expansion of process information to the PI System



A PI System based monitoring system has opened up our 'Energy Eyes'



Business Challenge

- How to measure energy use and assess performance

Solution

- RtEMIS installed on PI System

Results and Benefits

- PI System ideal for gathering data and analysis
- Measure it- Manage it!
- ***We know if we are having a good energy day!***



IRVING TISSUE

Thanks to those involved

- OSIsoft- system infrastructure supplier
- RtEMIS- software supplier
- ADM- install and set up
- ITD- business LAN
- Can-Technologies- electrical network
- Metso Automation- paper mill DCS
- Lakeside Controls- steam plant DCS



IRVING TISSUE

QUESTIONS?

Keith Kirkham

Energy Manager

Irving Tissue Toronto

Kirkham.Keith@irvingtissue.ca

416-246-6801



IRVING TISSUE